

V222





⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH


- Follow safe electrical work practices. See NFPA 70E in the USA, or applicable local codes.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Read, understand and follow the instructions before installing this product.
- Turn off all power supplying equipment before working on or inside the equipment.
- Use a properly rated voltage sensing device to confirm power is off.
 DO NOT DEPEND ON THIS PRODUCT FOR VOLTAGE INDICATION

Failure to follow these instructions will result in death or serious injury.

NOTICE

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations.
- The installer is responsible for conformance to all applicable codes.
- Mount this product inside a suitable fire and electrical enclosure.

DIMENSIONS



V222

20A SPST Enclosed Relay With Resistive HOA Monitor

Installer's Specifications

-40° to 60°C (-40° to 131°F)
10-90% RH, non-condensing
Electrical (@ rated current) 100,000 cycles;
Mechanical (unpowered) 10,000,000 cycles
LED ON=energized
14"(356mm) min.
il: 18AWG; Contacts: 12AWG; HOA monitor wires: 16AWG
277VAC RMS
13.4VAC/DC
4mA AC/DC
UL 508 enclosed device listing, pollution degree 2

INSTALLATION

Disconnect and lock out all power sources before beginning the installation.


- 1. Using the threaded nipple, connect the relay to the desired enclosure through a knock out hole.
- 2. Secure with the conduit nut provided.
- 3. Connect coil wires:
 - Choose the coil common lead (white with yellow stripe) and connect it to the common (-) source termination point.
 - Choose either the low voltage (10-30VAC/DC, white with blue stripe) or high voltage (208-277VAC, white with brown stripe) lead, depending on the application requirements, and connect it to the (+) source termination point.*

Note: When connecting the control side of this device (#18 wires) to power line circuits, provide currenting limiting at 7 amps max.

- 4. Connect relay contacts:
 - Choose the two solid orange wires (N.O. contact) and connect to the switched load.
- 5. Connect resistive HOA monitor wires:
 - Choose the two solid grey wires and connect them to a resistive (0-10k Ω) input in the control system.
- 6. Secure the enclosure and reconnect power.
- 7. Program the resistive input to the ranges listed.
- * Isolate or insulate all non-terminated wires according to local electrical code requirements, i.e. wire nut.




WIRING COLOR CODES



Resistive HOA Position Monitor






CONTACT AND COIL SPECIFICATIONS

TYPICAL COIL PERFORMANCE				
Coil Voltage 24VAC/DC, 208-277VAC				
Coil Current				
AC	DC			
75mA	32mA			
36mA	_			
49mA	_			
	C/DC, 208-277VA Coil Curr AC 75mA 36mA			


CONTACT RATINGS				
Resistive	20A(r)@240VAC 8A@28VDC			
Motor	14A@14VDC 250VAC, 1HP N.O. & N.C.			

WIRING EXAMPLE


Nipple mount directly to a panel



Nipple mount to a 2x or 4x electrical box



HOA POSITIONS





HAND Up position: contacts are closed.

OFF Middle position: contacts are open.

Down position: control system actuates the contacts.

PROGRAMMING THE RESISTIVE MONITOR

The resistive monitor is a 0-10 k Ω analog output for monitoring the HOA switch position. Please use the following ranges for the DDC scaling.

Condition	Range (Ω)*	Nominal Values without Wire Resistance $(\Omega)^*$
Line Open	Greater than 8630	n/a
HOA Off	5290 to 8630	6190
HOA Auto	2880 to 5289	3391
HOA On	1200 to 2879	1406
Line Shorted	Less than 1200	n/a

^{*} Ranges based on the presence of 0-1000 Ω of resistance due to wire. Average # of feet for 1000 Ω by wire AWG listed below.

Wire Type (AWG)†	Distance Allowed (ft.)
26	12,189
22	30,864
18	78,296

† All 2-wire runs