

VT8000 Room Controllers

VT8650 User Interface Guide

Rooftop Unit (RTU), Heat Pump and Indoor Air Quality (IAQ)

Firmware Revision 2.6




Table of Contents


- Safety Information 3
- Before You Begin..... 4
- Section 1**
- Introduction 6
- User and Integrator Screens 6
- Disclaimer 7
- BACnet Integration Guide References 7
- HMI Display..... 8
- Enter Setup Screen 9
- Section 2**
- User HMI for Hospitality 11
- User HMI for Commercial..... 12
- User HMI Show/Hide Options 13
- System Mode 14
- Fan Mode Settings 14
- Heating Only Configuration 15
- Setpoint Adjustment for Cooling Mode..... 15
- Setpoint Adjustment for Automatic Mode 16
- Other Functions..... 16
- Customizable Color Options 17
- Section 3**
- Network Screens 19
- Configuration Screens..... 33
- Setpoints Screens 53
- Display Screens 55
- Service View Screens 60
- Test Outputs Screens 70
- Language Selection Screens 72
- Clock - Schedule Screens..... 74
- Automatic Demand Response (ADR) Screen..... 78
- Wireless Screens..... 79
- Lua Screens 86
- Section 4**
- Appendix A: Terminal Correspondence 90

Safety Information

IMPORTANT INFORMATION

Read these instructions carefully and inspect the equipment to become familiar with the device before trying to install, operate, service or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.

 The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.

 This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury. The safety alert symbol shall not be used with this signal word.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Before You Begin

LOSS OF CONTROL

NOTICE

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and over travel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.¹
- Each implementation of equipment utilizing communication links must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in equipment damage.

ELECTROSTATIC DISCHARGE

NOTICE

STATIC SENSITIVE COMPONENTS

Circuit boards and option cards can be damaged by static electricity. Observe the electrostatic precautions below when handling controller circuit boards or testing components.

Failure to follow these instructions can result in equipment damage.

Observe the following precautions for handling static-sensitive components:

- Keep static-producing material such as plastic, upholstery, and carpeting out of the immediate work area.
- Store static-sensitive components in protective packaging when they are not installed in the drive.
- When handling a static-sensitive component, wear a conductive wrist strap connected to the component or drive through a minimum of 1 megohm resistance.
- Avoid touching exposed conductors and components leads with skin or clothing.

¹ For additional information about anticipated transmission delays or failures of the link, refer to NEMA ICS 1.1 (latest edition), *Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control* or its equivalent

SECTION 1

Introduction


Introduction

This guide shows the user interface instructions for the VT8650 Series Room Controller (RC) firmware revision 2.6 for users and integrators.

User and Integrator Screens

The VT8650 Room Controller has dynamic screens that show adjustable parameters and read-only status information. Some screens and parameters show only when a corresponding parameter is selected. Some screens show only on models with onboard Zigbee, optional Zigbee add-on module (VCM8000), optional Wi-Fi module (VCM8002) or paired Zigbee wireless sensor end devices (SED). The Lua selection on the Setup screen shows only if a Lua script is uploaded to the Room Controller.

See below legend screen details.



NOTE: When any change is made to a parameter, the value is automatically saved in memory when the next parameter is selected or another screen is opened. This event is true only if a parameter was changed locally on the RC. Making changes through BACnet will not have the same outcome. If changes need to be done remotely through BACnet, use priority 1, 2 or 3, or write to relinquish default (priority 17).

Disclaimer

Standby screen: The Room Controller incorporates TFT-type LCD technology, and therefore, necessary precautions are required to prevent the phenomenon of image retention (residual image) from occurring.

Image retention may occur when a static image is displayed on the screen for a prolonged period of time. This can cause a faint outline of the image to remain visible on the screen when the screen is changed via the user menu, or a different image is uploaded and selected to be displayed. To minimize and prevent image retention, it is recommended to select the **Screen save** setting on the **Standby screen** selection from the setup menu **"Display 1/3"** on page 55. This setting switches the display during periods of inactivity from the Home Screen.

It is recommended to use a black or medium gray image, or one with light color contrasts as the screen saver to prevent this phenomenon from occurring. If the display still exhibits this phenomenon, loading an all-black or all-medium gray image as the screen saver and displaying it for upwards of 5 hours continuously minimizes this effect.

NOTE: Avoid placing the Room Controller in poorly ventilated areas, or in areas that may create excess heat around the display.

BACnet Integration Guide References

To simplify cross-referencing between the User Interface Guide and the [BACnet Integration Guide](#), BACnet object properties are included in the Parameter Details tables as follows:


- **Object name.**
- **Instance number** and **object type prefix.** Object type prefixes are described as follows:
 - AI - Analog Input
 - AO - Analog Output
 - AV - Analog Value
 - BI - Binary Input
 - BO - Binary Output
 - BV - Binary Value
 - CSV - Comma-Separated Value
 - MSI - Multi-State Input
 - MV - Multi-State Value
- **Binary range values** (for BI, BO, BV, MSI and MV instance numbers) and **status enumeration** descriptions.

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Fan status Default value: Off MSI326 ○— Instance number	Fan Speed Status ○— Object name Status value: 1=Off, 2=Low, 3=Med, 4=High ○— Range values and enumeration

HMI Display

The User Human Machine Interface (HMI) is configurable and allows display functions such as Date, Time, Humidity, CO2 levels, Outdoor Temperature and Setpoint to be enabled or disabled by setting various parameters.




Enter Setup Screen



Touch and hold this point for 3 seconds to enter setup mode

Note: If a configuration/installer password is activated to prevent unauthorised access to the configuration menu parameters, a password entry prompt shows to prevent access to device configuration components.

SETUP 1/2



Network — BACnet MS/TP, Modbus, Zigbee and Wi-Fi network settings (Zigbee network settings appear only if Zigbee feature is available)

Configuration — Parameter configuration menu


Setpoints — Setpoint settings

Display — Display settings

Service view — Status display (Read Only)

Test Outputs — Test outputs settings

SETUP 2/2



Language Selection — Select language

Clock - Schedule — Set clock, schedule and occupancy

ADR — Automatic Demand Response

Wireless — Wireless Ecosystem settings (shows only if Zigbee feature is available)

LUA — Lua scripting (shows only if Lua script uploaded)

SECTION 2

Customized User HMI Display

User HMI for Hospitality

To select the User HMI configuration, refer to “Display 1/3” on page 55.

Hospitality 0	Hospitality 1	Hospitality 2	Hospitality 3
<ul style="list-style-type: none"> • Setpoint adjustment • System mode setting • Fan mode setting • Local unit scale adjustment • Local user language • User help menu 	<ul style="list-style-type: none"> • Setpoint adjustment • System mode setting • Fan mode setting • User help menu 	<ul style="list-style-type: none"> • Setpoint adjustment • Local unit scale adjustment • Local user language • User help menu 	<ul style="list-style-type: none"> • Setpoint adjustment • User help menu

NOTE: Parameters are model dependent and may not appear on certain models.

Hospitality 4	Hospitality 5	Hospitality 6
<ul style="list-style-type: none"> • Fully locked interface with no user settings 	<ul style="list-style-type: none"> • Setpoint adjustment • System mode setting • User help menu 	<ul style="list-style-type: none"> • Setpoint adjustment • System mode setting • Fan mode setting • Local unit scale adjustment • User help menu


User HMI for Commercial

Commercial 7




- Setpoint adjustment
- System mode setting
- Fan mode setting
- Unoccupied mode override
- User help menu

Commercial 8




- Setpoint adjustment
- Unoccupied mode override
- Local user language
- User help menu

Commercial 9




- Setpoint adjustment
- Unoccupied mode override
- User help menu

Commercial 10




- Unoccupied mode override

Commercial 11



- Setpoint adjustment
- System mode setting
- Unoccupied mode override
- User help menu

Commercial 12




- Offset setpoints adjustment
- System mode setting
- Local user language
- Fan mode setting
- User help menu

NOTE: The day/night setback button appears only in unoccupied mode in the Commercial HMIs 7 to 11. If UI17 input is configured as “override”, the day/night setback button does not show.

NOTE: Parameters are model dependent and may not appear on certain models.

User HMI Show/Hide Options


User HMI displays can be customized further by hiding the system status, fan status or help button. Each show/hide option is applicable to all User HMI configurations where the option is shown. To hide the option, select disabled for each display setup screen parameter. Refer to "Display 3/3" on page 59.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Control status Default value: Off MV112	System Status (BACnet object name: Control Status) Status value: 1=Off, 2=Cool, 3=Heat
Fan status Default value: Off MSI326	Fan Speed Status Status value: 1=Off, 2=Low, 3=Med, 4=High


System Mode



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
System mode Default value: Heat MV16	System Mode Off: Heating, Cooling and Dehumidification demands are ignored. Auto: Room Controller automatically toggles between Heating and Cooling modes to satisfy both Heating and Cooling demands. Dehumidification is allowed. Cool: Room Controller only satisfies Cooling demands, Heating demands are ignored. Dehumidification is allowed. Heat: Room Controller only satisfies Heating demands, Cooling demands are ignored. Dehumidification is allowed. Choices: 1=Off, 2=Auto, 3=Cool, 4=Heat

Fan Mode Settings



The Fan mode settings displayed on the home screen must be configured in the Fan menu tab of the Configuration menu.

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Fan mode Default value: Auto MV17	Fan Mode Choices: 1=On, 2=Auto, 3=Smart

Heating Only Configuration

09.26.2012 12:54 PM

Room 1705
Standby

Setpoint °C
23.5°

Humidity 45% | Outdoor 18°C

On/Off icon is used instead of system mode icon when sequence of operation is set to either heating only or cooling only.

Time and Date show only when a network time synchronisation command is received.

Setpoint Adjustment for Cooling Mode

In Cooling mode, the setpoint displayed in the bar is the current occupied cooling setpoint. During occupied setpoint adjustment, the large digits are temporarily used to show occupied cooling setpoint while it is adjusted.

Normal temperature display resumes after setpoint is adjusted and actual occupied cooling setpoint shows in setpoint bar.

09.26.2012 12:54 PM

Room 1705
Standby

Cooling Setpoint °C
23.5°

Humidity 45% | Outdoor 18°C


Cooling mode or cooling only sequence of operation.

Setpoint Adjustment for Automatic Mode

In automatic mode, setpoint showing at the top of the set point bar located directly under the red line represents the actual occupied cooling setpoint.

During occupied setpoints adjustment, large digits are temporarily used to display the occupied Cooling Setpoint or occupied Heating Setpoint. The actual setpoint is dependent on the last effective demand (heating or cooling). The setpoint on top of the blue line represents the actual occupied heating setpoint. The differential between the occupied heating and cooling setpoint is defined by the minimum deadband configuration parameter.

Normal temperature display resumes after setpoints are adjusted and the actual occupied heating and cooling setpoints show in the setpoint bar.




Other Functions

Local humidity shows when RH display is enabled on the setup display screen, from either the internal onboard sensor or a wireless sensor end device selected by the RH sensor parameter on the setup configuration screen.

CO2 shows when CO2 display is enabled on the setup display screen, from either the optional CO2 detection sensor module or a wireless sensor end device selected by the CO2 source parameter on the setup configuration screen.

Outdoor temperature shows when receiving a valid networked outdoor temperature value or a temperature sensor connected to UI23.




Customizable Color Options

To select the color option, refer to "Display 1/3" on page 55.



White



Green



Blue



Grey



Dark Grey



Pink



Purple



Red



Orange



Black

SECTION 3

Integrator Setup Screens

Network Screens

User can select wired BACnet / Modbus / Zigbee wireless protocol (when Zigbee feature is available).

NOTICE


UPGRADE OF ZIGBEE FIRMWARE REVISION 24 TO 30

The upgrade from Zigbee firmware revision 24 to 30 will **not** support the Green Power Sensor (SED-CO2-G-5045 or SED-TRH-G-5045). It will therefore need to be recommissioned.

There is also a new "Security Levels" parameter for the Zigbee network (see page 21):

- **Low** (default value) is fully backwards compatible with Zigbee Home Automation 1.2 devices, and therefore compatible with all of our sensors.
- **Normal** or **High** (needs to be selected by user) is only compatible with Green Power and Zigbee 3.0 network standard (Leedarson sensors). If the Normal or High Security Level is selected with old NYCE or Centralite sensors, they will be removed from the network.

Failure to follow these instructions can result in equipment being disconnected from the network.



Onboard Zigbee detection (Read Only)

Type of expansion module:
Zigbee, IP or BAC. IP (Read Only)

Wired protocol (BACnet MS/TP or Modbus)

NOTICE

DISABLED WIRED NETWORK PROTOCOL

The RS-485 transceiver connected to pins 13 and 14 is not installed on Room Controllers with part numbers VT8650U5000N and VT8650U5500NP, thus disabling the wired network protocol (BACnet MS/TP or Modbus). The network screens and the optional Wi-Fi protocol BACnet/IP will still operate normally.

When ordering, make sure the Room Controller specifications comply with your system design.

PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
Onboard prot. Read Only	Onboard Protocol Onboard Zigbee detection Display Readings: None, Zigbee
Optional prot. Read Only	Optional Protocol Requires Zigbee add-on module (VCM8000) or Wi-Fi module (VCM8002). BACnet/IP is enabled from the Configuration Web Page or the Uploader Tool. None: No module detected Zigbee: Zigbee module detected IP: Wi-Fi module detected BAC. IP: Wi-Fi module detected and BACnet/IP enabled Display Readings: None, Zigbee, IP or BAC. IP
Wired protocol Default value: BAC MSTP	Wired Protocol None: No wired protocol configured BAC MSTP: BACnet MS/TP network protocol Modbus: Modbus network protocol Choices: None, BAC MSTP or Modbus

ZIGBEE NETWORK 1/3

The Zigbee Network screen shows only in models with onboard Zigbee or optional Zigbee add-on module.

When creating a Zigbee network, there must be one and only one device with its Node Type set to Coordinator.
 For a Zigbee network with a single Room Controller (RC), the RC is set as Coordinator to pair with the Sensor End Devices (SED).
 Setting the RC back to Router will remove the paired SEDs.
 For a Zigbee network with a Building Management System (BMS) server or controller paired to multiple RCs, the BMS is set as Coordinator and the RCs are set as Router. The Coordinator BMS controls the pairing of the Router RCs to the SEDs

Note: Before pairing any Zigbee devices, the network must first be created by the Coordinator.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Node type Default: Router	Node Type Sets device to act as Router or Coordinator in a network. Coord.: Creates the network and manages the binding of wireless devices. Router: Joins a network created by a coordinator (Coordinator permit join must be set to 'ON'). Choices: Coord. or Router
PAN ID Default value: 0	Zigbee Pan ID Personal Area Network Identification that links specific Room Controllers to specific Zigbee coordinators. For every Room Controller reporting to a coordinator, set the SAME PAN ID value both on the coordinator and the Room Controller. Note: The default value of 0 is NOT a valid PAN ID and causes Zigbee to be disabled. Range: 1 to 65535
Channel Default value: 10	Zigbee Channel The channel (wireless frequency) on which the Zigbee network transmits and receives data. The channel of the Coordinator must match that of the routers to exchange data. The default value of 10 is NOT a valid channel and causes Zigbee to be disabled. The valid range of available channels is from 11 to 25. Using channels 15, 20, and 25 is recommended. Channel 25 is considered as being the best one because it is furthest from the Wi-Fi channels. Range: 10 to 25

Configuration Parameters Default Value	Significance and Adjustments
<p>Security Default value: Low</p>	<p>Security Levels</p> <p>Note: Changing between Zigbee Security levels does not require re-creating the Zigbee network, or re-commissioning sensors.</p> <p>Low: Disables new security features in Zigbee 3.0 to be fully backwards compatible with Zigbee Home Automation 1.2 devices, and therefore compatible with all of our sensors.</p> <p>Normal: Enables the typical new features of Zigbee 3.0. This means that legacy Zigbee Home Automation 1.x devices cannot join a Normal security network. Compatible with the following sensors:</p> <ul style="list-style-type: none"> • SED-WDS-P-5045 • SED-WDC-G-5045 • SED-CMS-P-5045 • SED-WMS-P-5045 • SED-MTH-G-5045 • SED-TRH-G-5045 • SED-C02-G-5045 <p>High: Enables the Zigbee 3.0 high security network joining. The high security level will encrypt the initial network key transport from the network coordinator to the joining Room Controller. This will protect the joining process from eavesdropping attacks (also known as sniffing or snooping attacks). Your network coordinator, such as a BMS server or controller, must be compatible with the Zigbee 3.0 standard. To start the network join, the Room Controller's IEEE address and install code must be transferred to the network coordinator (refer to "ZigBee Network 3/3" on page 23).</p> <p>Note: Before starting the network join, make sure to set the PAN ID and set the Node type to Router. High security is supported only when the Node Type is set to Router, it is disabled when the Node type is set to Coordinator.</p> <p>Important! Selecting the Normal Security option will result in the removal of legacy sensors from the network.</p> <p>Choices: Low, Normal or High</p>
<p>Network Status Read Only MSI2</p>	<p>Zigbee Network Status</p> <p>Shows the current status of the Zigbee network.</p> <p>Not det.: Zigbee module not detected Pwr on: Zigbee module detected but not configured No NWK: Zigbee configured but no network joined Joined: Zigbee network joined Online: Communicating (Exchanging data)</p> <p>Display Readings: 1=Not det., 2=Pwr on, 3=No NWK, 4=Joined, 5=Online</p>
<p>Permit join Default value: Off</p>	<p>Permit Join</p> <p>Changing this value to "Off" on the Coordinator prevents any new Zigbee devices from joining the network.</p> <p>Permit join can be On/Off when the Room Controller is a Coordinator, however the parameter is read only when the Room Controller is a router. If not set to off manually the Permit join will stay On for 3 hours.</p> <p>Choices: On or Off</p>

ZIGBEE NETWORK 2/3

2/3 ZigBee Network

COM address

254

Short address

0x0000

IEEE address:
00124B0018E25296

ZigBee revision:
30.0.0-13-8c3477d











PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
COM address Default value: 254 AV10	COM Address Room Controller networking address. For wireless models, the use of the COM address is not mandatory. The COM address is an optional way to identify a device on the network and is recommended if used with a BMS. It is Mandatory for BACnet. Range: 0 to 254
Short address Default value: 0 Read Only	Zigbee Short Address The unique Zigbee short address is generated once a wireless device joins a Zigbee network.
IEEE address Read Only CSV10	Zigbee IEEE Address The extended IEEE address (MAC address) is a unique worldwide identifier of the onboard Zigbee or optional Zigbee add-on module.
Zigbee revision Read Only CSV9	Zigbee Firmware Revision Shows the Zigbee firmware revision number.

ZIGBEE NETWORK 3/3

The 3/3 Zigbee Network screen shows only when the security level is set to high.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
IEEE address Read Only CSV10	Zigbee IEEE Address The extended IEEE address (MAC address) is a unique worldwide identifier of the onboard Zigbee or optional Zigbee add-on module.
Install code Read Only	Install Code The install code is used as a shared key to make an initial secure connection between the network coordinator and the Room Controller when joining the Zigbee 3.0 high security network (refer to “Security Levels” on page 21). Once the Room Controller has successfully joined the network, a new key is created for future secure connections. The install code contains a key of 16-byte hexadecimal numbers plus a 2-byte cyclic redundancy check (CRC) code at the end. Warning: To maximize security, a new random install code is generated each time the Room Controller is power cycled, or its Zigbee settings are changed. Make sure to set the Zigbee PAN ID and set the Security Level to High before transferring the Install Code.
QR code Read Only	QR Code The QR code provides an easy way to transfer the Room Controller’s IEEE address and install code to the network coordinator. The QR code format is defined by the Zigbee 3.0 standard. The QR code is scanned with the mobile app for your gateway commissioning software. If your software does not support QR code data transfer, you can read the IEEE address and install code and enter them into a web page or provide them over the phone to the system administrator. Format: Z\$A:{IEEE address}\$I:A{Install code}

BACNET NETWORK SETTINGS

BACnet network screen shows when BACnet MS/TP is selected in wired protocol parameter.



PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
COM address Default value: 254 AV10	COM Address Room Controller networking address. Default value of 254 disables BACnet communication for the Room Controller. Range: 0 to 254
Network units Default value: SI MV6	Network Units Network units transmitted over the BACnet network. NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller. SI: Network units shown as International Metric units. Imperial: Network units shown as Imperial units. Choices: 1=SI, 2=Imperial
Network lang. Default value: English MV7	Network Language Network language/object names transmitted over network. Choices: 1=English, 2=French, 3=Spanish
Baud rate Default value: Auto MV8	BACnet Baud Rate Leave the value at Auto unless instructed otherwise as this automatically detects BACnet baud rate. Choices: 1=9600, 2=19200, 3=38400, 4=57600, 5=76800, 6=115200, 7=Auto
BACnet status Read Only	BACnet Status Read Only value shows if a BACnet Network is detected or not. Display Readings: Online or Offline
BACnet PRate Default value: 4 AV16	BACnet Stack Poll Rate Rate at which a BACnet stack is processed, in milliseconds. Range: 1 to 5.

BACNET INSTANCE NUMBER

The default BACnet instance number is generated by the model number and COM address of the Room Controller. For example, the instance number of a VT8650U5500BP with a COM address of 57 is generated as "86057".

The default instance number appears first. To change the instance number, use number pad and press **Accept and save**.

Tap "R" icon to reset to automatic instance addressing.



MODBUS NETWORK SETTINGS


Modbus network screen shows when Modbus is selected in wired protocol parameter.

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Comm address Default value: 254	Communication Address Valid address range is set at 1 to 247 and each Modbus device must have a unique address. Other values not recommended for Modbus. Default value of 254 disables Modbus communication for the Room Controller. Range: 0 to 254
Network units Default value: SI	Measurement Units Network units transmitted over the Modbus network. NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller. Imperial: network units shown as Imperial units. SI: network units shown as International Metric units. Choices: Imperial or SI
Baud rate Default value: 19200	Modbus Baud Rate Automatically detects Modbus baud rate. Choices: 57600, 38400, 19200, 9600, and 4800
Parity Default value: Even	Parity Determines how the parity bit of the character's data frame is set to detect any errors in the sent/receives frame. Choices: None, Odd and Even

Wi-Fi 1/5

The Wi-Fi Network screen shows only in models with optional Wi-Fi module (VCM8002).



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Module status Read Only MSI315	Wi-Fi Module Status Displays the current status of the Wi-Fi module. It would normally display Ready when the Wi-Fi module is operational. Status value: 1=Offline, 2=Initializing, 3=Ready, 4=Booting, 5=Resetting, 6=Fail, 7=Testing
Device Name Read only CSV4	Wi-Fi Device Name The device name can be set and edited from the Configuration Web Page.
Firmware version Read only CSV5	Wi-Fi Firmware Version Shows the Wi-Fi Module firmware revision number.
MAC address Read only CSV6	MAC Address The MAC address is a unique hardware identifier of the Wi-Fi Module.

Wi-Fi 2/5



The Password needed to connect to the Access Point Wi-Fi network


The SSID of the Access Point created by the Wi-Fi module. You can add your device to this network to access the Configuration Web Page

When connected to the Access Point, browse to this IP address to access the Configuration Web Page

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Access point Default value: Disabled	Access Point On this screen the access point can be enabled or disabled as needed. Choices: Enabled or Disabled

Wi-Fi 3/5



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Wi-Fi status Read Only MSI316	Wi-Fi Status When not connected to a Wi-Fi network the status remains Idle. Once the RC is on your preferred Wi-Fi network, the status will be displayed as Ready. Status value: 1=Idle, 2=Associate, 3=Config., 4=Ready, 5=Online, 6=Disconn., 7=Failure
Signal strength Read Only MSI327	Wi-Fi Network Signal Strength Signal strength of the Wi-Fi network. Range: 1=Unknown, 2=Weak, 3=Fair, 4=Good, 5=Excellent
SMTP status Read Only MSI318	SMTP Server Status Status of the email SMTP server. Email notifications are enabled and configured from the Configuration Web Page. Status value: 1=Unknown, 2=Disabled, 3=Offline, 4=Online
SSID Read only CSV7	Wi-Fi Network SSID SSID of the building Wi-Fi network that the device is connected to. The SSID is set from the Configuration Web Page.
IP address Read only CSV8	Wi-Fi Network IP Address When connected to the building Wi-Fi network shown above, browse to this IP address to access the Configuration Web Page.

Wi-Fi 4/5



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Facility Expert Read Only MSI319	Facility Expert Enabled Shows whether the Facility Expert system is Disabled or Enabled. Status value: 1=Disabled, 2=Enabled
Status Read Only MSI323	Facility Expert Status Shows the current status of the Facility Expert system. Range: 1=Disabled, 2=Offline, 3=Connect., 4=Online, 5=Failure, 6=Unknown
Last communication time Read Only	Last Communication Time
MAC address Read only CSV6	MAC Address The MAC address is a unique hardware identifier of the Wi-Fi Module.

WI-FI 5/5




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
<p>Factory reset? Default value: No</p>	<p>Erase All</p> <p>Accepting Yes for both and then tapping 'Push to accept' will restore the Wi-Fi module to the factory settings, erase all configuration data and revert the Wi-Fi module firmware to the factory firmware version.</p> <p>NOTES:</p> <ul style="list-style-type: none"> • If you lose or forget your password for the Configuration Web Page, you must do a Factory Reset of the Wi-Fi module. • If your Wi-Fi module was connected to Facility Expert, you will need to contact your Facility Expert Administrator before the device can be reconnected after a Factory Reset.
<p>Are you sure? Default value: No</p>	

Wi-Fi BACNET NETWORK SETTINGS

BACnet network screens are shown when the wired protocol is set to BACnet or a Wi-Fi module is installed with BACnet/IP enabled. Only one BACnet protocol can be used at a time, either the wired protocol BACnet MS/TP (BACnet Network screens), or the Wi-Fi BACnet IP (Wi-Fi screens). BACnet/IP is enabled from the Configuration Web Page or the Uploader Tool. BACnet object name, instance number and range: BACnet IP Status, MSI317, 1=Disabled, 2=Enabled.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Network units Default value: SI MV6	Network Units Network units transmitted over the BACnet network. NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller. SI: Network units shown as International Metric units. Imperial: Network units shown as Imperial units. Choices: 1=SI, 2=Imperial
Network lang. Default value: English MV7	Network Language Network language/object names transmitted over network. Choices: 1=English, 2=French, 3=Spanish
Port Default value: 0 Read Only	Port The unique short address of Wi-Fi BACnet IP

BACNET INSTANCE NUMBER

The default BACnet instance number is generated by the model number and COM address of the Room Controller. For example, the instance number of a VT8650U5500BP with a COM address of 57 is generated as “86057”.

The default instance number appears first. To change the instance number, use number pad and press **Accept and save**. The BACnet instance number can also be changed from the Configuration Web Page or the Uploader Tool.

Tap “R” icon to reset to automatic instance addressing.

Configuration Screens

CONFIGURATION 1/11



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
<p>UI16 config Default value: None MV46</p>	<p>UI16 Configuration</p> <p>None: No function will be associated with the input. Input can be used for remote network monitoring.</p> <p>Rem NSB: Remote night setback (NSB) timer clock input. The scheduling gets set as per the binary input and provides low cost setback operation via a dry contact.</p> <p>Motion NO and Motion NC: Advanced PIR occupancy functions using a Normally Open (NO) or Normally Closed (NC) remote PIR motion sensor.</p> <p>Window: Forces system to disable any current heating or cooling action by Room Controller when window is open.</p> <p>Fan lock: When (G) Fan output is activated, if this input is not activated after 10 seconds, the Room Controller disables Heat and Cool outputs and display "Fan Lock" alarm.</p> <ul style="list-style-type: none"> • Open contact = No airflow alarm • Closed contact = Airflow present, normal operation <p>Choices: 1=None, 2=Rem NSB, 3=Motion NO, 4=Motion NC, 5=Window, 6=Fan lock</p>
<p>UI17 config Default value: None MV47</p>	<p>UI17 Configuration</p> <p>None: No function associated with input.</p> <p>Door Dry: Room Controller goes to standby mode when door is opened then closed followed by no presence detection for the next 10 seconds if the local PIR is used in this application. The "Occupancy Command" (refer to "Options" on page 77) must be set to "Local Occupancy" and "Occupancy Source" (refer to page 36) must be set to "Motion".</p> <p>Override: A closed contact forces the Room Controller to go in occupied mode. An open contact keeps the current occupancy mode.</p> <p>Filter: backlit flashing filter alarm shows on the Room Controller screen when input is energized.</p> <p>Service: backlit flashing Service alarm shows on Room Controller screen when input is energized.</p> <p>Choices: 1=None, 2=Door Dry, 3=Override, 4=Filter, 5=Service</p>

Configuration Parameters Default Value	Significance and Adjustments
UI19 config Default value: None MV49	UI19 Configuration This input is used for a wired CO2 sensor. None: No function associated with input, however input can be used for remote network monitoring. CO2: Using the CO2 level measured by a wired CO2 sensor (0~2000 ppm = 0~10 Vdc), the Outside Air damper (Econo) will modulate between "Econo min pos" to "Econo max pos" following the "Min CO2" and "Max CO2" setpoints. Choices: 1=None, 2=CO2
UI20 config Default value: RS MV185	UI20 Configuration The UI20 Remote Sensor (RS) can be wired to a room temperature sensor or a mixed air temperature sensor. If RS is selected, make sure the Temp. sensor parameter value is set to Wired, refer to "Configuration 3/11" on page 37. This input will change the RS parameter name from Remote temp. to Mixed air temp., refer to "Service view 1/10" on page 60. None: No function associated with input RS: Remote temperature sensor. MAT: Mixed air temperature sensor. Choices: 1=None, 2=RS, 3=MAT
Setpoint func. Default value: Attach SP MV58	Setpoint Function Local setpoint settings to set the local setpoint interface for the User. Dual SP: "Minimum" Deadband, Heat and Cool Setpoints can be adjusted independently. Attach SP: "Fixed" Deadband in occupied mode, Heat and Cool setpoints always follow each other, separated by Deadband value (acts like a single setpoint). Choices: 1=Dual SP, 2=Attach SP
Mode button Default value: Normal MV111	Mode Button Changes the behavior of the system mode button functionality and hides/shows temperature setpoints on main screen. Normal: System mode button switches between 'Off', 'Auto', 'Cool' and 'Heat'. Also displays temperature Setpoints on main screen. Off-Auto: System mode button switches between 'Off' and 'Auto'. Hides temperature Setpoints on main screen. NOTE: Setting 'Mode button' to 'Off-Auto' forces the 'Setpoint func.' parameter to 'Attach SP'. Choices: 1=Normal, 2=Off-Auto

CONFIGURATION 2/11




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Fan cont. heat Default value: On MV95	Fan Control in Heating Mode Off: Fan (terminal G), when heating stages (terminals W1 & W2) are solicited, will not be energized. The fan is controlled by the equipment fan limit control. Valid only for Auto fan mode. On fan mode leaves the fan always on. On: Room Controller always controls the fan (terminal G). Valid for On or Auto fan mode. For multi-stage models, fan control applies to W1 & W2. Choices: 1=Off, 2=On
Fan delay Default value: On MV12	Fan Delay On: fan mode will leave the fan always on and extends fan operation by 60 seconds after the call for heating or cooling ends. Valid only for Auto fan mode. Off: fan delay not operational Choices: 1=Off, 2=On
Standby mode Default value: Absolute MV11	Standby Mode Configuration Standby setpoints used for control. Absolute: Standby entered values are used for standby mode. Offset: Occupied setpoints +/- Standby diff. used for standby mode. Choices: 1=Absolute, 2=Offset
Standby diff. Default value: 4°F (2°C) AV46	Standby Temperature Differential When Standby mode is set to 'offset', standby setpoints are calculated as follows: Standby cool: Cool setpoint + Standby diff. Standby heat: Heat setpoint - Standby diff. Refer to "Setpoints Screens" on page 53 to define Standby cool and Standby heat values. Range: 1 to 5°F (0.5 to 2.5°C), using 1.0 °F (0.5 °C) increments.

Configuration Parameters Default Value	Significance and Adjustments
Power-up delay Default value: 10 Sec. AV76	Power-up Delay On initial power up of the Room Controller there is a delay before any operation is authorized (fan, cooling or heating). This can be used to sequence the start up of multiple Room Controllers in one location. Range: 10 to 120 seconds
Occupancy src Default value: Motion MV110	Occupancy Source Motion: Occupancy status is received from a motion sensor from a wired, wireless or local PIR sensor Schedule: Occupancy status is determined by the schedule Mot. occ: Occupied when scheduled occupied AND when motion is detected. Mot. unoc: Occupied when scheduled occupied OR when motion is detected. Choices: 1=Motion, 2=Schedule, 3=Mot. occ., 4=Mot. unoc.

CONFIGURATION 3/11



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Standby time Default: 0.5 hrs AV67	Standby Time Time between the moment where the PIR cover detects last movement in the area, and the time which the Room Controller stand-by setpoints become active. Note: This parameter is not active when the "Door" function is used (wired or wireless). Range: 0.5 to 24.0 hours (0.5 hour increments)
Unocc. time Default: 0.0 hrs AV68	Unoccupied Time Time between the moment where the Room Controller toggles to stand-by mode, and the time which the Room Controller unoccupied mode and setpoints become active. Note: Default value of 0.0 hours disables the unoccupied timer. This prevents the Room Controller from being able to switch from stand-by mode to unoccupied mode when PIR functions are used. Range: 0.0 to 24.0 hours (0.5 hour increments)
Temp. occ. time Default value: 2 hrs AV62	Temporary Occupancy Time The time the Room Controller stays in override mode before reverting back to unoccupied mode. When the Room Controller is in unoccupied mode, pressing the on-screen Override icon or closing the contact on UI17, configured as "Remote Override", sets the Room Controller to Override mode for defined time period, and uses the Occupied Cooling and Heating setpoints. Range: 0.0 to 24.0 hours

Configuration Parameters Default Value	Significance and Adjustments
Temp. sensor Default value: Wired MSI309, MV145	Room Temperature Sensor Sets the source of the indoor room temperature. This parameter allows the user to designate either the Room Controller or any of the paired wireless devices that support temperature to act as the source for the room temperature. Wired: sets the thermistor connected to UI20 (RS) as the source to report room temperature. Internal: sets the Room Controller as the source for the room temperature. WL 1 to WL 20: sets the selected Zigbee wireless device as the source for the room temperature. Only one device can be selected. Note: The Room Controller uses the internal temperature sensor only if the UI20 (RS) terminal is empty. If a valid temperature sensor is connected to the UI20 terminal, the Room Controller will use the sensor as the control point. Disconnecting the sensor, or if the sensor is faulty, the Room Controller will automatically revert to its internal temperature sensor. Choices: 1=Wired, 2=Internal, 3= WL IO, 4 to 23=WL 1 to WL 20
Deh. hysteresis Default value: 5% RH AV72	Dehumidification Hysteresis Used only if dehumidification sequence is enabled. Range: 2 to 20% RH
Deh. lockout Default value: Disabled MV13	Dehumidification Lockout Enables or disables dehumidification based on central network requirements from the BAS front end. Disabled: Dehumidification Not Authorized Enabled: Dehumidification Authorized Choices: 1=Disabled, 2=Enabled

CONFIGURATION 4/11




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
<p>Cooling CPH Default value: 4 CPH AV85</p>	<p>Cooling CPH</p> <p>Cooling Output Cycles Per Hour</p> <p>CPH is used to “modulate” On/Off outputs controlling equipment such as compressors. When the Room Temperature is within the Proportional Band, the output performs 3 or 4 CPH. A higher CPH represents a higher accuracy of control at the expense of wearing mechanical components faster.</p> <p>Note: The CPH does not limit the number of Cycles Per Hour. It is limited by the “Anti short cycle” parameter. 4 CPH is typical for Rooftop applications.</p> <p>Range: 3 to 4 CPH</p>
<p>Heating CPH Default value: 4 CPH AV84</p>	<p>Heating CPH</p> <p>Heating Stages Cycles per Hour</p> <p>CPH is used to “modulate” On/Off outputs controlling equipment such as compressors. When the Room Temperature is within the Proportional Band, the output performs 3 to 8 CPH. A higher CPH represents a higher accuracy of control at the expense of wearing mechanical components faster.</p> <p>For multi-stage models, heat cph applies to W1 & W2. A CPH value between 6 - 8 is recommended for applications with electric heating. For gas applications set CPH to 4 and for oil applications set CPH to 3.</p> <p>Range: 3 to 8 CPH</p>

Configuration Parameters Default Value	Significance and Adjustments
Frost protec. Default value: Off MV55	Frost Protection If the Room Temperature drops below 42°F (5.6°C), the Fan and the Heat will be activated until the Room Temperature rises over 42°F (5.6°C). Off: No room frost protection On: Room frost protection enabled in all system modes at 42°F (5.6°C). Frost protection is enabled even if System mode is 'Off'. Choices: 1=Off, 2=On
BO1 aux. config Default value: NO MV92	BO1 Auxiliary Output Configuration Output to directly follow the main Occupancy and Fan On commands. NO: Occ or St-By = Contact Closed / Unoccupied = Contact Opened NC: Occ or St-By = Contact Opened / Unoccupied = Contact Closed. Choices: 1=NO, 2=NC
Anti short cycle Default value: 2 min AV86	Anti Short Cycle Time Minimum On time and minimum Off time of operation time for stages. IMPORTANT: anti-short cycling can be set to 0 minutes for equipment that possess their own anti cycling timer. Do not use this value unless the equipment is equipped with an internal timer. Failure to do so can damage the equipment. Range: 0 to 5 minutes
Min. sup. heat Default value: 64°F (18°C) AV97	Minimum Supply Heat Controls the modulating heating output to maintain the supply air temperature setpoint (min. sup. heat). Apply if "Heat Stages" parameter is set to 0 (Analog Heat on UO11). In Occupied or Override mode, the output will modulate to maintain a minimum Supply Air temperature. Conditional to SAT sensor installed, System Mode = Heat or Auto and OAT < SH Lockout. Range: 50°F to 72°F (10°C to 22°C)

CONFIGURATION 5/11



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments																														
<p>Prop. band Default value: 3.0 AV65</p>	<p>Proportional Band</p> <p>Adjusts proportional band used by Room Controller PI control loop.</p> <p>Note: Default value of 3 gives satisfactory operation in most normal installation cases. The use of a superior proportional band different than the factory value is normally warranted in applications where Room Controller location is problematic and leads to unwanted cycling of the unit. A typical example is a wall mounted Room Controller installed between return and supply air feeds and is directly influenced by the supply air stream of unit.</p> <p>Range: 3 to 10</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="background-color: #008000; color: white;">Value</th> <th colspan="2" style="background-color: #008000; color: white;">Effective Proportional Band</th> </tr> <tr> <td></td> <th style="background-color: #008000; color: white;">Fahrenheit</th> <th style="background-color: #008000; color: white;">Celsius</th> </tr> </thead> <tbody> <tr><td>3.0</td><td>3</td><td>1.2</td></tr> <tr><td>4.0</td><td>4</td><td>1.7</td></tr> <tr><td>5.0</td><td>5</td><td>2.2</td></tr> <tr><td>6.0</td><td>6</td><td>2.8</td></tr> <tr><td>7.0</td><td>7</td><td>3.3</td></tr> <tr><td>8.0</td><td>8</td><td>3.9</td></tr> <tr><td>9.0</td><td>9</td><td>5.0</td></tr> <tr><td>10.0</td><td>10</td><td>5.6</td></tr> </tbody> </table>	Value	Effective Proportional Band			Fahrenheit	Celsius	3.0	3	1.2	4.0	4	1.7	5.0	5	2.2	6.0	6	2.8	7.0	7	3.3	8.0	8	3.9	9.0	9	5.0	10.0	10	5.6
Value	Effective Proportional Band																														
	Fahrenheit	Celsius																													
3.0	3	1.2																													
4.0	4	1.7																													
5.0	5	2.2																													
6.0	6	2.8																													
7.0	7	3.3																													
8.0	8	3.9																													
9.0	9	5.0																													
10.0	10	5.6																													

Configuration Parameters Default Value	Significance and Adjustments
Heat stages Default value: 2 stages AV87	Number of Heating Stages Sets number of Heating Stages applicable to 2 stage models only. 0 Stages: Only (UO11) modulating 0-10Vdc output is used for Heating. W1 & W2 are disabled. 1 Stage: Only W1 (BO8) terminal is used. W2 is disabled. 2 Stages: Both W1 (BO8) and W2 (UO9) terminals are used in sequence. Choices: 0, 1 or 2 stages
Cool stages Default value: 2 stages AV75	Number of Cooling Stages Sets number of Cooling Stages. 1 Stage: Only Y1 (BO3) terminal is used. Y2 is disabled. 2 Stages: Both Y1 (BO3) and Y2 (BO2) terminals are used in sequence. Choices: 1 or 2 stages
Econo. config Default value: Off MV72	Economizer Configuration Enables or disables the economizer functionality. Off: Economizer deactivated On: Economizer activated Choices: 1=Off, 2=On
Changeover SP Default value: 55°F (13°C) AV95	Changeover Setpoint In Cooling mode, the outside air temperature value at which the cooling gets switched over from mechanical (compressor) to free cooling (economizer). Range: 14°F to 70°F (-10°C to 21°C)
Mech. cooling Default value: Off MV79	Mechanical Cooling Allowed Allows operation of mechanical cooling if free cooling (economizer) cannot maintain the cooling setpoint. Off: Applies when the mixed air temperature sensor is installed after the mechanical cooling refrigeration coils. In this case, mechanical cooling never operates at the same time as free cooling. On: Applies when the mixed air temperature sensor is installed before the mechanical cooling refrigeration coils in the mixing plenum. In this case, mechanical cooling is allowed when the free cooling (economizer operation) cannot maintain the cooling setpoint. Range: 1=Off, 2=On

CONFIGURATION 6/11



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Heat lockout Default value: 120°F (49°C) AV91	Heating Lockout from Outside Air Temperature Disables mechanical heating operation when Outdoor Temperature is higher than the "Heating Lockout" value. The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller (UI23) or via a BACnet front end (network). Range: -15°F to 120°F (-26°C to 49°C)
Cool lockout Default value: -40°F (-40°C) AV93	Cooling Lockout Disables mechanical cooling operation when Outdoor Temperature is lower than the "Cool Lockout" value. The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller (UI23) or via a BACnet front end (network). The Economizer functionality (Free-cooling) can still be enabled during the Cooling Lockout. Range: -40°F to 95°F (-40°C to 35°C)
Discharge HL Default value: 120°F (49°C) AV99	Discharge High Limit Discharge air high temperature value at which the heating stages get locked out. Range: 70°F to 150°F (21°C to 65°C)
Discharge LL Default value: 45°F (7°C) AV20	Discharge Low Limit Discharge air low temperature value at which the cooling stages get locked out. Range: 35°F to 65°F (2.0°C to 19.0°C)

Configuration Parameters Default Value	Significance and Adjustments
<p>SH lockout Default value = 32°F (0°C) AV98</p>	<p>Supply Heat Lockout</p> <p>Disables heating operation if Outdoor Air Temperature (OAT) is higher than “SH Lockout” temperature. The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller or via a BACnet front end (network).</p> <p>Note: valid only if “Heat Stages” parameter is set to 0 (Analog Heat on UO11).</p> <p>Range: -15°F to 120°F (-26°C to 49°C)</p>
<p>FA range Default value: 0 CFM (0 l/s) AV96</p>	<p>Fresh Air Range Upper Limit</p> <p>Sets the upper limit (reading range) of the “airflow measuring station” (eg. for 0~1,000 CFM station, set “FA Range” to 1,000). If set to 0 CFM, this function is disabled, and the fresh air damper control will be based on the “Min/Max CO₂” and “Econo Min/Max Pos” values if set to a value other than 0.</p> <p>Do not change Econo Min/Max Pos if FA range is set to a value greater than 0.</p> <p>Range: 0 to 20,000 CFM ±10 increments (0 to 9440 l/s ±5 increments)</p>

CONFIGURATION 7/11




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments										
Econo min pos Default value: 0% AV78	Economizer Minimum Position Minimum Outside Air damper position when Room Controller is in Occupied, Standby or Override mode and Fan status is ON. If Room Controller is Unoccupied mode and/or the Fan is Off, Outside Air damper position goes to 0%. Range: 0% to 100%										
Econo max pos Default value: 100% AV81	Economizer Maximum Position Maximum Outside Air damper position when Room Controller is in Occupied, Standby or Override mode and Fan status is ON. This is valid only for Economizer, CO ₂ and Airflow functions. Range: 0% to 100%										
<p>Note: The Room Controller air damper position and output signal is based on a 0-10Vdc analog actuator application. Many installations utilize 2-10 VDC actuators, which cannot be switched to 0-10 Vdc control logic. The following chart indicates the appropriate equivalent damper positions for use with 2-10Vdc actuators.</p>											
Outside air percentage	0%	5%	10%	15%	20%	25%	30%	35%	40%	45%	50%
Setting for 0-10 Vdc Actuator	0%	5%	10%	15%	20%	25%	30%	35%	40%	45%	50%
Setting for 2-10 Vdc Actuator	20%	24%	28%	32%	36%	40%	44%	48%	52%	56%	60%
Outside air percentage	55%	60%	65%	70%	75%	80%	85%	90%	95%	100%	
Setting for 0-10 Vdc Actuator	55%	60%	65%	70%	75%	80%	85%	90%	95%	100%	
Setting for 2-10 Vdc Actuator	64%	68%	72%	76%	80%	84%	88%	92%	96%	100%	

Configuration Parameters Default Value	Significance and Adjustments
Min fresh air Default value: 0 CFM (0 l/s) AV21	Minimum Fresh Air Minimum fresh air required (minimum outside airflow setpoint). Effective only in Occupied, Standby or Override mode and Fan status is ON. If FA Range is set to value other than 0 CFM, the fresh air damper position control will be based on the Min/Max CO2 and Min/Max Fresh Air values. If Room Controller is in Unoccupied mode and/or the Fan is Off, the damper position goes to 0%. Range: 0 to 20, 000 CFM ± 10 increments (0 to 9440 l/s ± 5 increments) The value set cannot exceed the value of FA Range parameter.
Max fresh air Default value: 0 CFM (0 l/s) AV22	Maximum Fresh Air Maximum fresh air allowed (maximum outside airflow setpoint). Effective only in Occupied, Standby or Override mode and Fan status is ON. If FA Range is set to value other than 0 CFM, the fresh air damper position control will be based on the Min/Max CO2 and Min/Max Fresh Air values. Range: 0 to 20, 000 CFM ± 10 increments (0 to 9440 l/s ± 5 increments) The value set cannot exceed the value of FA Range parameter.
Min CO2 Default value: 800 ppm AV23	Minimum CO2 Minimum CO2 level setpoint. Effective only in Occupied, Standby or Override mode and Fan status is ON. The Outside Air damper modulates to maintain the CO2 level between "Min CO2" and "Max CO2". If Room Controller is in Unoccupied mode and/or the Fan is Off, Outside Air damper position goes to 0%. Range: 0 to 5000 ppm
Max CO2 Default value: 1200 ppm AV24	Maximum CO2 Maximum CO2 level setpoint. Effective only in Occupied, Standby or Override mode and Fan status is ON. The Outside Air damper modulates to maintain the CO2 level between "Min CO2" and "Max CO2". Range: 0 to 5000 ppm

CONFIGURATION 8/11




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Application Default value: Rooftop MV119	Application Sets Room Controller operating logic for either a Rooftop or a Heat Pump application. Note: if the Heat Pump Unit (HPU) does not have an O/B terminal (reversing valve), set this parameter to Rooftop. Choices: 1=Rooftop, 2=Heatpump
High BP Default value: 90°F (32.0°C) AV82	High Balance Point In Heating or Auto mode, it is the outside air temperature value at which the auxiliary heat is cut off. If the temperature exceeds this value, only the heat pump is used to maintain the heating setpoint. NOTE: Function enabled only if outside air temperature value is populated (not -40°F/°C). The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller or via a BACnet front end (network). Range: 34°F to 90°F (1.0°C to 32.0°C)
Low BP Default value: -12 °F (-24.5 °C) AV83	Low Balance Point In Heating, Cooling or Auto mode, it represents the outside air temperature value at which the heat pump operation will be cut off. If the temperature falls below this value, only the auxiliary heat is used to maintain the heating setpoint. NOTE: Function enabled only if outside air temperature value is populated (not -40°F/°C). The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller or via a BACnet front end (network). Range: -40°F to 30°F (-40°C to -1.0°C)

Configuration Parameters Default Value	Significance and Adjustments
Comf. or econ. Default value: Comfort MV116	Comfort or Economy Mode Sets the operation and interaction mode of the heat pump with the auxiliary heat. Comfort mode: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized to satisfy the same heating setpoint. Economy mode: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized to satisfy only when the temperature drops 2.0°F (1.1°C) below the heating setpoint. Selecting economy mode adds a deadband between the heat pump & auxiliary heat in heating mode. The actual temperature maintained will be lower than the true heating setpoint to maximize the heat pump operation. When the outdoor air temperature drops below the low balance point, the deadband gets eliminated and the auxiliary heat maintains the true heating setpoint alone. Choices: 1=Comfort, 2=Economy
Rev. valve Default value: O MV117	Reversing Valve Operation Heat pump reversing valve operation O: energize valve in cooling operation B: energize valve in heating operation Choices: 1=O, 2=B
Comp. interlock Default value: Off MV118	Compressor - Auxiliary Interlock Sets the operation and interaction mode of the heat pump with the auxiliary heat. Off: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized at the same time as the heat pump stage. Typically applies when the air handler heat pump coil is installed before the auxiliary heat (all electric systems). On: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized and the heat pump is cut off. Typically applies when the air handler heat pump coil is installed after the auxiliary heat (add on systems) There is a 2 minute delay to restart the heat pump when the auxiliary heat is shut down. Choices: 1=Off, 2=On

CONFIGURATION 9/11



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Main password Default value: 0 AV56	Main Password Sets a protective access password to prevent unauthorized access to configuration menu parameters. A default value of "0" will not prompt for a password or lock access to the configuration menu. Range: 0 to 9999.
User password Default value: 0 AV57	User Password Sets a protective access password to prevent User unauthorized access to main screen adjustments. A default value of "0" will not prompt for a password. Range: 0 to 9999.
Schedule menu Default value: Enabled MV73	Schedule Menu Toggles activation of schedule menu direct access. Disabled: Schedule Menu can only be accessed through the Setup Menu screens. Enabled: Schedule Menu is directly accessible from the main screen via a touch in the upper corner. Dis. no. clk: Schedule Menu can only be accessed through the Setup Menu screens. Clock does not show. En. no. clk: Schedule Menu is directly accessible from the main screen via a touch in the upper corner. Clock does not show. Choices: 1=Disabled, 2=Enabled, 3=Dis.no.clk, 4=En.no.clk

Configuration Parameters Default Value	Significance and Adjustments
USB access Default value: Enabled	USB Access Enables/disables USB communication with the Room Controller (RC). Enabled: USB communication with the RC is enabled, so the Uploader tool can be used to upgrade firmware, standby images, Lua script etc. Disabled: USB communication with the RC is disabled, so the Uploader tool cannot be used with the device. Choices: Enabled, Disabled
Smart recovery Default value: Off MV71	Enable Smart Recovery Off: No smart recovery. The occupied schedule time is the time at which the system will restart. On: Smart recovery active. The occupied schedule time is the time at which the desired occupied temperature will be attained. The Room Controller automatically optimizes the equipment start time. In any case, the latest a system will restart is 10 minutes prior to the occupied period time. Smart recovery is automatically disabled if UI16 is configured to remote NSB. Choices: 1=Off, 2=On

NOTICE


UNAUTHORIZED USB ACCESS

When commissioning is complete, it is recommended to minimize access points on the Room Controller:

- Disable USB access via the Configuration screen or Commissioning via USB on the Admin tab of the Configuration Web Page
- Enable main password to lock the setup screens
- Enable user password to lock the main screen adjustments (optional)
- Lock the display screen (optional)
- Use strong and unique Wi-Fi Module admin password

Failure to follow these instructions may lead to unauthorized users accessing the Wi-Fi Module or the Room Controller.

CONFIGURATION 10/11



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Calib. temp. Default value: 0°F (0°C) AV7	Calibrate Room Temperature Sensor Room temperature sensor calibration. Offset can be added or subtracted to actual displayed room temperature. Range: ± 5.0°F (± 2.5°C)
Calib. OS temp. Default value: 0°F (0°C) AV74	Calibrate Outside Temperature Sensor Outside air temperature sensor calibration. Offset that can be added or subtracted to the actual displayed outdoor temperature. Range: ± 5.0°F (± 2.5°C)
Calib. humid. Default value: 0.0 %RH AV8	Calibrate Humidity Sensor Offset that can be added or subtracted to actual displayed humidity. Range: ± 15.0 %RH
RH sensor Default value: Internal MSI313, MV149	Relative Humidity Sensor Sets the source of the indoor room humidity. This parameter allows the user to designate either the Room Controller or any of the paired wireless devices that support humidity to act as the source for the room humidity. None: Relative Humidity source disabled. Internal: Sets the Room Controller as the source for the room humidity. WL 1 to WL 20: Sets the selected Zigbee wireless device as the source for the room humidity. Only one device can be selected. Choices: 1=None, 2=Internal, 3 to 22=WL 1 to WL 20
CO2 source Default value: Local MV150	CO2 Source Sets the source of the indoor CO2. This parameter allows the user to designate either the optional CO2 detection sensor module (VCM8001) or any of the paired wireless devices that support CO2 to act as the source for the room CO2. None: CO2 source disabled. Local: Sets the optional CO2 detection sensor module as the source for the room CO2. WL 1 to WL 20: Sets the selected Zigbee wireless device as the source for the room CO2. Only one device can be selected. Choices: 1=None, 2=Local, 3 to 22=WL 1 to WL 20

CONFIGURATION 11/11



PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Erase all? Default value: No	Erase All Accepting Yes for both and then tapping 'Push to accept' returns all values to the factory default settings with the exception of the following: <ul style="list-style-type: none"> • COM address • Network Units • Network Language • Baud Rate • BACnet Instance • Device Name • Screen Contrast • Lua Script Note: Node type in Zigbee Network screen returns to default value (Router).
Are you sure? Default value: No	

Setpoints Screens

SETPOINTS 1/2



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Unocc. cool Default value: 80°F (27°C) AV44	Unoccupied Cool Setpoint Cooling Temperature setpoint used by the Room Controller when in Unoccupied mode. Range: 54 to 100°F (12.0 to 37.5°C)
Standby cool Default value: 78°F (25.5°C) AV42	Standby Cool Setpoint Cooling Temperature setpoint used by the Room Controller when in Standby mode. Range: 54 to 100°F (12.0 to 37.5°C)
Occ. cool Default value: 75°F (24°C) AV40	Occupied Cool Setpoint Cooling Temperature setpoint used by the Room Controller when in Occupied or Override mode. Range: 54 to 100°F (12.0 to 37.5°C)
Occ. heat Default value: 72°F (22°C) AV39	Occupied Heat Setpoint Heating Temperature setpoint used by the Room Controller when in Occupied mode. Range: 40 to 90°F (4.5 to 32.0°C)
Standby heat Default value: 69°F (20.5°C) AV41	Standby Heat Setpoint Heating Temperature setpoint used by the Room Controller when in Standby mode. Range: 40 to 90°F (4.5 to 32.0°C)
Unocc. heat Default value: 62°F (17°C) AV43	Unoccupied Heat Setpoint Heating Temperature setpoint used by the Room Controller when in Occupied or Override mode. Range: 40 to 90°F (4.5 to 32.0°C)

SETPOINTS 2/2





PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Default heat Default value: 72°F (22°C) AV45	Default Heating Setpoint Used for hospitality applications in stand-alone mode only to reset the occupied setpoints when a new guest enters the room. When the Room Controller is in unoccupied mode, any movement detected by a wired, wireless or local PIR sensor changes the occupancy mode to occupied modes and uses the "Default Heating Setpoint" as the new occupied setpoints. NOTE: This functionality is only valid when Stand-by mode = Offset and "Setpoint Func" is set to "Attached". Range: 65 to 80°F (18.5 to 26.5°C)
Min. deadband Default value: 3°F (1.5°C) AV63	Minimum Deadband Temperature offset between the Cooling and Heating setpoints to ensure that Cooling setpoint is always warmer than the Heating setpoint Cooling setpoint \geq (Heating setpoint + Deadband) Range: 2 to 5°F (1.0 to 2.5°C)
Max heating Default value: 90°F (32°C) AV58	Heating Setpoint Limit Maximum Occupied, Unoccupied, Standby and Override Heating setpoints limit. Range: 40 to 90°F (4.5 to 32.0°C)
Min. cooling Default value: 54°F (12°C) AV59	Cooling Setpoint Limit Minimum Occupied, Unoccupied, Standby and Override Cooling setpoint limit. Range: 54 to 100°F (12.0 to 37.5°C)
Supply air SP Default value: 55°F (12°C) AV94	Supply Air Setpoint Free cooling supply air setpoint when economizer mode is enabled. Range: 50 to 90°F (10.0 to 32.0°C)
Dehum. SP Default value: 50%RH AV71	Dehumidification Setpoint Used only if dehumidification sequence is enabled. Range: 30 to 95% RH

Display Screens

DISPLAY 1/3



IPS Screen

PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
User HMI Default value: 0 AV2	User HMI Sets layout of icons on the home screen for various applications. For more information, refer to “Customized User HMI Display” on page 10. Range: 0 to 12
Color Default value: White MV2	HMI Color Change background color of the display screen. Choices: 1=White, 2=Green, 3=Blue, 4=Grey, 5=Dark grey, 6=Pink, 7=Purple, 8=Red, 9=Orange, 10=Black
Main display Default value: Temp. MV3	Main Display Shows temperature or setpoint on main display. Choices: 1=Temp., 2=Setpoint
Standby screen Default value: No MV32	Standby Screen When the device is left unattended for 150 seconds, the standby image will appear. A custom image can be uploaded using the Uploader Tool. No: No Stand by image (Screen dims when no motion is detected) Yes: Stand by Image is displayed after 150 seconds Occ. Only: Standby image displays after 150 seconds. Screen turns off after 30 minutes only in occupied or override mode. Screen sav: Standby image displays after 150 seconds. Screen turns off after 30 minutes only in unoccupied or standby mode Choices: 1=No, 2=Yes, 3=Occ. Only, 4=Screen sav

Configuration parameters Default Value	Significance and Adjustments
Lock screen Default value: No MV148	Lock Screen Prevents the user from accessing the Room Controller until a password is entered. Screen lockout starts 150 seconds after no activity on the Room Controller (when standby image appears). This functionality is enabled only if the below conditions are met: <ul style="list-style-type: none"> • Standby image loaded • Standby Screen = “Yes” or “Screen” • User Password = not 0 Choices: 1=No, 2=Yes
Contrast Default value: 0	Contrast Control screen contrast and brightness. Range: -5 to 5
Contrast Read Only	IPS Screen Contrast Starting with firmware revision 2.6, some RCs are shipped with an In-Plane Switching (IPS) screen that does not need contrast adjustment. Thus, the contrast parameter is read only with a default value of -2. To identify an RC with an IPS screen, "IPS" will appear on the RC's box label. Note: RCs with an IPS screen cannot be downgraded to a firmware revision older than 2.6. Display Default: -2

DISPLAY 2/3




PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
Language Default value: English MV4	Display Language Select language for main display. Choices: 1=English, 2=French, 3=Spanish, 4=Chinese, 5=Russian, 6=Arabic, 7=Bulgarian, 8=Czech, 9=Danish, 10=Dutch, 11=Finnish, 12=German, 13=Hungarian, 14=Indones., 15=Italian, 16=Norwegian, 17=Polish, 18=Portug., 19=Slovak, 20=Swedish, 21=Turkish, 22=Japanese, 23=Hebrew
Units Default value: °C MV51	Temperature Scale Changes the local display units. Refer to Network Units to change the network units broadcasted over the network. Choices: 1=°C for SI, 2=°F for Imperial.
Low backlight Default value: 60% AV3	Low Backlight Sets display backlight intensity. This feature is activated (screen dims) 150 seconds after no activity on the Room Controller. Adjustable: 0 to 100%.
Night backlight Default value: 5% AV4	Night Backlight Sets backlight display intensity. Parameter only available for models with motion/light detectors. The screen backlight progressively decreases down to this setting when room is dark. This feature is used mostly in hospitality applications when a darker non obtrusive lighting level is desired when room is dark. Adjustable: 0 to 100%.

Configuration Parameters Default Value	Significance and Adjustments
RH display Default value: Disabled MV70	Relative Humidity Display Shows humidity level in room in %RH. Disabled: Do not display %RH Enabled: Display %RH Choices: 1= Disabled, 2= Enabled
CO2 display Default value: Enabled MV146	CO2 Display Shows carbon dioxide level in room in ppm. Disabled: Do not display % CO2 level Enabled: Display CO2 level Note: The CO2 value will only be displayed on the Room Controller home screen if an optional CO2 detection sensor module is installed or a Zigbee wireless CO2 device is paired, and if there is a valid value. Choices: 1= Disabled, 2= Enabled

DISPLAY 3/3




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Fan status Default value: Enabled MV180	Display the Fan Status icon Hides the fan status in the upper right corner of the User HMI display. Applicable to all User HMI configurations where the fan status is shown. Refer to "User HMI Show/Hide Options" on page 13. Choices: 1=Disabled, 2=Enabled
System status Default value: Enabled MV181	Display the System Status icon Hides the system status in the upper right corner of the User HMI display. Applicable to all User HMI configurations where the system status is shown. Refer to "User HMI Show/Hide Options" on page 13. Choices: 1=Disabled, 2=Enabled
Help button Default value: Enabled MV182	Display the Help button Hides the help button in the lower right corner of the User HMI display. Applicable to all User HMI configurations where the help button is shown. Refer to "User HMI Show/Hide Options" on page 13. Choices: 1=Disabled, 2=Enabled

Service View Screens

The service view screens show the current status of certain points locally on the Room Controller. These points can also be viewed through the network. Service view values are **Read Only** values but allow a service contractor to visualize the status of key functionality to correctly diagnose operational system issues.

SERVICE VIEW 1/10



PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
Room temp. Read Only AV100	Room Temperature Shows the current room temperature from the configured temperature source.
Remote temp. Read Only AV105	UI20 Remote Temperature Shows the temperature of the sensor connected to UI20 (RS) terminal. The UI20 config parameter value must be set to RS, refer to "Configuration 1/11" on page 33.
Mixed air temp. Read Only AV125	Mixed Air Temperature Shows the temperature of the sensor connected to UI20 (RS) terminal. The UI20 config parameter value must be set to MAT, refer to "Configuration 1/11" on page 33.
Outdoor temp. Read Only AV101	Outdoor Temperature Shows the current value of the outdoor temperature.
Supply temp. Read Only AV102	UI22 Supply Temperature Shows supply air temperature as measured by the sensor.

SERVICE VIEW 2/10



PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
Effective occ. Read Only MSI33	Effective Occupancy Shows as occupied, unoccupied, standby or override. Display Readings: 1=Occupied, 2=Unoccupied, 3=Override, 4=Standby
PI cool demand Read Only AO22	PI Cooling Demand Proportional Integral Cooling Demand Display Readings: 0-100%
PI heat demand Read Only AO21	PI Heating Demand Proportional Integral Heating Demand Display Readings: 0-100%
Cool dem. limit Read Only AV89	Cooling Demand Limit Display Readings: 0-100%
Heat dem. limit Read Only AV88	Heat Demand Limit Display Readings: 0-100%
Econo. demand Read Only AO23	Economizer Demand Display Readings: 0-100%

SERVICE VIEW 3/10



* Only for models with onboard Zigbee or optional Zigbee add-on module.

PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
UI16 binary Read Only BI29	UI16 Binary Input Shows status of input. Display Readings: 1=Activated, 2=Not activ
UI17 binary Read Only BI30	UI17 Binary Input Shows status of input. Display Readings: 1=Activated, 2=Not activ
UI19 analog Read Only AV108	UI19 Analog Input Shows voltage level of wired CO2 sensor. 0.0 Vdc = 0ppm, 10.0 Vdc = 2000ppm Display Readings: 0.0 to 10.0 Vdc
Airflow level Read Only AV107	Airflow Level Shows the amount of air (in cubic feet/minute or litres/second) that flows through a particular device. Display Readings: 0 to 20,000 CFM (0 to 9440 l/s)
Zigb. PIR inst. Read Only BV200	Zigbee PIR Sensor Installed Shows if Zigbee Passive Infrared Sensor wireless motion sensor is paired to a Room Controller or not. NOTE: This parameter is for Zigbee wireless motion sensors only. Display Readings: 1=Off, 2=On
Zigb. sens. mot. Read Only BV201	Zigbee Sensor Motion Shows if motion is detected by any of the Zigbee wireless motion sensors. NOTE: This parameter is for Zigbee wireless motion sensors only. Display Readings: 1=Motion, 2=No Motion


SERVICE VIEW 4/10



PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
Window alarm Read Only BV35	Window Alarm Shows On if there is a Window alarm and shows Off if there is no Window alarm. This feature is for both wired and wireless sensors. Display Readings: 1=Off, 2=On
Service alarm Read Only BV37	Service Alarm Shows On if there is a Service alarm and shows Off if there is no Service alarm. Display Readings: 1=Off, 2=On
Filter alarm Read Only BV36	Filter Alarm Shows On if there is a Filter alarm and shows Off if there is no Filter alarm. Display Readings: 1=Off, 2=On
Fan lock alarm Read Only BV39	Fan Lock Alarm Shows On if there is a problem detected on the Fan. Display Readings: 1=Off, 2=On
CO2 alarm Read Only BV41	CO2 Alarm Shows On if the CO2 level (local, wired or wireless) is higher than the “Max CO2” parameter located on the Configuration screen. Display Readings: 1=Off, 2=On
Low air alarm Read Only BV42	Low Fresh Air Alarm Shows if the fresh air flow is lower than the “Min fresh air” parameter located on the Configuration screen. Display Readings: 1=Off, 2=On

SERVICE VIEW 5/10



PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
Frost alarm Read Only BV43	Frost Protection Alarm Shows if Frost Alarm is active or not. Display Readings: 1=Off, 2=On
Recovery Read Only BV40	Smart Recovery Status Shows if Smart Recovery is active or not. Display Readings: 1=Off, 2=On
Local motion Read Only BV32	PIR Local Motion Shows if Motion alarm is active or not. Display Readings: 1=No Motion, 2=Motion
Deh. status Read Only BV38	Dehumidification Status Shows if dehumidification is active or not. Display Readings: 1=Off, 2=On
Room humidity Read Only AV103	Room Humidity Shows the current room humidity percentage from the configured humidity source. Refer to RH sensor parameter in "Configuration 10/11" on page 51 to select RH source.


SERVICE VIEW 6/10



PARAMETER DETAILS

Configuration parameters Default Value	Significance and Adjustments
UO9 config Read Only MV96	UO9 Configuration Display Readings: 1=Analog, 2=Binary, 3=Relay RC, 4=Relay RH
UO10 config Read Only MV97	UO10 Configuration Display Readings: 1=Analog, 2=Binary, 3=Relay RC
UO11 config Read Only MV98	UO11 Configuration Display Readings: 1=Analog, 2=Binary
UO12 config Read Only MV99	UO12 Configuration Display Readings: 1=Analog, 2=Binary


SERVICE VIEW 7/10



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
UI19 type Read Only MV140	UI19 Input Type Display Readings: 1=Therm., 2=Binary, 3=Voltage
UI20 type Read Only MV141	UI20 Input Type Display Readings: 1=Therm., 2=Binary, 3=Voltage
UI22 type Read Only MV142	UI22 Input Type Display Readings: 1=Therm., 2=Binary, 3=Voltage
UI23 type Read Only MV143	UI23 Input Type Display Readings: 1=Therm., 2=Binary, 3=Voltage
UI24 type Read Only MV144	UI24 Input Type Display Readings: 1=Therm., 2=Binary, 3=Voltage


SERVICE VIEW 8/10



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
CO2 eff. source Read Only MSI324	CO2 Effective Source Shows the configured source or the indoor CO2. Display Readings: 1=None, 2=Internal, 3=Error, 4=Wired, 5 to 24=WL 1 to WL 20
CO2 err. code Default value: 0 Read Only	CO2 Error Code Error code 0x0001 shows if there is an error with the sensor.
CO2 level Read Only AV106	CO2 Level Shows CO2 level in PPM. Display Readings: 0 to 5000 PPM
CO2 FW rev. Read Only	CO2 Firmware Revision Shows the Firmware version of the installed CO2 sensor module.
CO2 S/N Read Only	CO2 Serial Number Shows the serial number of the installed CO2 sensor module.

SERVICE VIEW 9/10



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Eff. sys. mode Read Only MSI314	Effective System Mode Shows the current operating mode of the system. For example, when the system is in Auto mode, this parameter shows whether it is currently heating or cooling. Display Readings: 1=Cool, 2=Heat
Eff. setpoint Read Only AI329	Effective Setpoint Shows the temperature setpoint value currently in use by the system.

SERVICE VIEW 10/10



The Device Name (BACnet name) consists of the model number followed by the COM address (MAC address). The BACnet name can be changed via the BACnet front end and the new name appears on the above screen.


For example, when a VT8650U5500BP Room Controller with a MAC address of 41 is connected to a network, its default Device Name is VT8650U5500BP-41 and its default BACnet Device ID is 86041.

Firmware Revision shows the Firmware version currently installed on the Room Controller. Upgrading to a newer Firmware version deletes the previous Firmware version, however it is possible to set the Room Controller to an earlier Firmware version with the Uploader Tool.

Zigbee Revision shows the Firmware version of an onboard Zigbee or optional Zigbee add-on module.

Test Outputs Screens

TEST OUTPUTS



NOTICE

SAFE OPERATION ENVIRONMENT

Use high caution when manually enabling outputs so as to not cause damage to equipment. It is the responsibility of the Installer or Service Contractor to maintain a safe operation environment during usage.

Failure to follow these instructions can result in equipment damage.

Note 1: The Test Outputs screen allows manual override of specified outputs. After any output state is overridden, the command is cancelled after 1 minute of screen inactivity (auto exit to main screen) or when page is exited.

Note 2: These parameters can also be changed via BACnet and the changed parameter background will turn red to indicate the parameter's value had been overridden. The overridden value remains even if the user exits the main screen

Note 3: Test Outputs values are LIVE. Any output gets displayed immediately for any value change according to the following:

1. If any BACnet priority array (1 - 16) includes a value, the displayed state background shows in red.
2. When toggling a value on the screen, the output directly energizes according to the selected value.
3. After any output state gets modified, all overrides get cancelled after 1 minute of button inactivity, or if you scroll from one screen to another screen.

Note 4: Test Outputs UO10 to UO12 are dependent on control type configuration. If mode is set to Floating or On/Off, binary options show. If mode is set to Analog, analog options show.

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
BO1 aux. out Default value: Off BO98	BO1 Auxiliary Binary Output Choices: 1=Off, 2=On
G fan status Default value: Off BO25	G Fan Status Choices: 1=Off, 2=On
Y1 status Default value: Off BO26	Y1 Status Choices: 1=Off, 2=On
Y2 status Default value: Off BO27	Y2 Status Choices: 1=Off, 2=On
W1 status Default value: Off BO28	W1 Status Choices: 1=Off, 2=On
W2/OB status Default value: Off BO29	W2/OB Status Choices: 1=Off, 2=On
UO10 binary Default value: Off BO94	UO10 Binary Output Choices: 1=Off, 2=On
UO11 binary Default value: Off BO101	UO11 Binary Output Choices: 1=Off, 2=On
U1O2 binary Default value: Off BO102	UO12 Binary Output Choices: 1=Off, 2=On
UO9 analog Default value: 0.0 Vdc AO125	UO9 Analog Output Range: 0.0 Vdc to 10.0 Vdc, using 0.1 Vdc increments
UO10 analog Default value: 0.0 Vdc AO126	UO10 Analog Output Range: 0.0 Vdc to 10.0 Vdc, using 0.1 Vdc increments
UO11 analog Default value: 0.0 Vdc AO123	UO11 Analog Output Range: 0.0 Vdc to 10.0 Vdc, using 0.1 Vdc increments
UO12 analog Default value: 0.0 Vdc AO124	UO12 Analog Output Range: 0.0 Vdc to 10.0 Vdc, using 0.1 Vdc increments

Language Selection Screens

LANGUAGE SELECTION



Only English, French, Spanish, Chinese, and Russian are enabled by default and are accessible to users cycling through languages on the display settings menu screen. To change the language selection settings, tap a language on the screen and then use the arrow buttons to disable or enable it.

NOTE: English is always enabled.


PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
French Default value: Enabled MV101	French Choices: 1=Disabled, 2=Enabled
Spanish Default value: Enabled MV102	Spanish Choices: 1=Disabled, 2=Enabled

Configuration Parameters Default Value	Significance and Adjustments
Chinese Default value: Enabled MV103	Chinese Choices: 1=Disabled, 2=Enabled
Russian Default value: Enabled MV104	Russian Choices: 1=Disabled, 2=Enabled
Arabic Default value: Disabled MV120	Arabic Choices: 1=Disabled, 2=Enabled
Czech Default value: Disabled MV122	Czech Choices: 1=Disabled, 2=Enabled
Danish Default value: Disabled MV123	Danish Choices: 1=Disabled, 2=Enabled
Dutch Default value: Disabled MV124	Dutch Choices: 1=Disabled, 2=Enabled
Finnish Default value: Disabled MV125	Finnish Choices: 1=Disabled, 2=Enabled
German Default value: Disabled MV126	German Choices: 1=Disabled, 2=Enabled
Hebrew Default value: Disabled MV156	Hebrew Choices: 1=Disabled, 2=Enabled
Hungarian Default value: Disabled MV127	Hungarian Choices: 1=Disabled, 2=Enabled
Indonesian Default value: Disabled MV128	Indonesian Choices: 1=Disabled, 2=Enabled
Italian Default value: Disabled MV129	Italian Choices: 1=Disabled, 2=Enabled
Japanese Default value: Disabled MV155	Japanese Choices: 1=Disabled, 2=Enabled
Norwegian Default value: Disabled MV130	Norwegian Choices: 1=Disabled, 2=Enabled
Polish Default value: Disabled MV131	Polish Choices: 1=Disabled, 2=Enabled
Portuguese Default value: Disabled MV132	Portuguese Choices: 1=Disabled, 2=Enabled
Slovak Default value: Disabled MV133	Slovak Choices: 1=Disabled, 2=Enabled
Swedish Default value: Disabled MV134	Swedish Choices: 1=Disabled, 2=Enabled
Turkish Default value: Disabled MV135	Turkish Choices: 1=Disabled, 2=Enabled

Clock - Schedule Screens


SCHEDULE MENU



Note: The Clock- Schedule Menu screen is directly accessible from the main setup screen.

CLOCK

The Clock settings screen allows the device's internal time settings to be changed (current time, day, month, year and weekday options), as well as to choose between a 12 hour AM / PM display or 24 hour display.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Time format Default value: AM-PM MV5	Time Format Current time display format. Choice between 12 hour (AM - PM) time format or 24 hour time format. Note: Changing the value of this parameter automatically changes the format of the displayed value of the time parameter. Choices: 1=AM-PM, 2=24 Hours
Time Default value: current time at power up	Time Standard time display, 12 hour AM-PM or 24 hour format determined by the Time Format parameter value.
Year Default value: 2019	Year Current year Range: 2000 - 2100
Month Default value: Jan.	Month Current month Range: Jan. - Dec.
Day Default value: 1	Date Current date Range: 1 - 31
Weekday Default value: Monday Read Only	Current Day Automatically set based on data received from Year/Month parameters. Range: Monday - Sunday
Time source Default value: None Read Only MSI325	Time Source Shows the source that most recently set the time on the Room Controller. Display Readings: 1=None, 2=Local, 3=BACnet, 4=NTP, 5=Cloud

SCHEDULE

There are seven different schedule setting screens, one for each day of the week. Each day can have different scheduled events where the Room Controller is set to Occupied status or back to Unoccupied status. The Room Controller can use the appropriate setpoints (back and forth) up to three times per day.




Identified by day of the week (Sunday through Saturday)

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Occupied 1 - 3 Default value: None	Occupied 1 - 3 Defines a time when the Room Controller is automatically set to use the Occupied setpoint. Note: There are 3 separate Occupied parameter entries Range: 00:00 - 23:59
Unoccupied 1 - 3 Default value: None	Unoccupied 1 - 3 Defines a time when the Room Controller is automatically set to use the Unoccupied setpoint. Note: There are 3 separate Occupied parameter entries Range: 00:00 - 23:59

OPTIONS

The options settings allow the Room Controller to function in Occupied or Unoccupied mode following a defined Schedule type set by the user.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Occupancy cmd Default value: Occupied MV10	Occupancy Command Loc occ: occupancy is determined by local sequences (either PIR or schedule, as configured under Occ. source). Occupied: force occupied mode. Unocc: force unoccupied mode. Choices: 1=Loc occ, 2=Occupied, 3=Unocc.
Schedule type Default value: 7 days MV136	Schedule Type 7 days: Independent scheduling identified by day of the week (Sunday - Saturday) 5+1+1 days: Weekdays scheduling and Independent Weekend scheduling identified as Weekdays, Saturday and Sunday 5+2 days: Weekdays scheduling and Weekend scheduling identified as Weekdays and Weekend Choices: 1=7 days, 2=5+2 days, 3=5+1+1 day

Automatic Demand Response (ADR) Screen

Automatic Demand Response (ADR) feature is used to reduce energy load when electric grid contingencies threaten supply-demand balance.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Permission Default value: Off MV152	ADR Permission Used to permit the ADR to be applicable or not to change the room controller setpoints setting or not. Off: The Load Shedding Demand will not be permitted. On: The Load Shedding Demand will be permitted. Choices: 1=Off, 2=On
Shed status Default value: Off Read Only BV49	Load Shedding Status Displays the status of the Load Shedding Demand, whether it is active (On) or not (Off). The Load Shedding status is On when the Permission is On, Shed demand is On, and the Shed Override is Off. Off: Load Shedding Demand is not activated. On: Load Shedding Demand is activated. Display Readings: 1=Off, 2=On
Shed demand Default value: Off Read Only BV48	Load Shedding Demand Sets the request to initiate Load Shedding. This demand can only be set through BACnet by the local Utility company. Off: No Load Shedding Demand is received or the Shedding demand is disabled. On: Received the Load Shedding Demand or received the signal to activate Load shedding. Display Readings: 1=Off, 2=On

Configuration Parameters Default Value	Significance and Adjustments
Shed offset Default value: 4°F (2°C) AV211	Load Shedding Offset Used to change the effective setpoints in occupied, standby and unoccupied modes. For example, when “Shed status” is On and Room Controller is in occupied mode: The cooling setpoint is calculated as follows: Occupied cooling setpoint = occupied cooling setpoint + Load shedding offset. The heating setpoint is calculated as follows: Occupied heating setpoint = occupied heating setpoint - Load shedding offset. Choices: 4°F to 10°F (2°C to 5.5°C)
Shed override Default value: Off Read Only BV50	Load Shedding Override Displays whether the user disabled the ADR request by the utility company. When the demand shed is applied, the user can override the ADR settings from its original setpoints settings. Off: Allows shed load demand request from utility company (setpoint will change according to shed offset) On: Rejects or cancels shed load demand request from utility company (setpoints remain the same). Display Readings: 1=Off, 2=On

Wireless Screens


WIRELESS MENU

The Wireless screen shows only in models with onboard Zigbee or optional Zigbee add-on module.



ECOSYSTEM SETTINGS

The Ecosystem Settings screens show the network status, the number of paired devices as well as information for each paired device. A maximum of 20 Zigbee wireless devices can be paired to each Room Controller. Tap forward arrow to obtain information on each paired Zigbee device.



PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
Network status Default value: Not det. Read Only MSI2	Zigbee Network Status Shows current status of Zigbee network. Pwr on: Zigbee module detected but not configured No NWK: Zigbee configured but no network joined Joined: Zigbee network joined Online: Communicating Display Readings: 1=Not det., 2=Pwr on, 3=No NWK, 4=Joined, 5=Online
Permit join Default value: Off	Permit Join Setting to 'On' allows the Room Controller to pair with a Zigbee device. Value must be set to 'On' to pair with initial device and then set to 'Off' if user wants to prevent additional Zigbee devices from joining the network. Changing this value to "Off" on the Coordinator prevents any new Zigbee devices from joining the network. Permit join can be On/Off when the Room Controller is a coordinator, however the parameter is read only when the Room Controller is a router. Permit join stays On for 3 hours. On: Allows Room Controller to pair with Zigbee wireless device Off: Prevents Room Controller from pairing with Zigbee wireless device, or prevent any additional Zigbee devices from joining network. Choices: On or Off

Configuration Parameters Default Value	Significance and Adjustments
Permit timeout Default value: 0 Read Only	Permit Join Timeout Allows Zigbee devices to join the Coordinator Room Controller for 180 minutes from the moment it is set to ON. Once the timer elapses, no devices will be able to join the network. NOTE: Permit Join parameter must be set to 'On' to enable this feature. Range: 0 or 180 minutes
Paired devices Default value: 0 Read Only AI330	Paired Zigbee Devices Shows the number of Zigbee wireless devices currently paired with the Room Controller. A maximum of 20 Zigbee wireless devices can be paired with each Room Controller. Display Readings: 0 to 20 devices

DEVICE 1-20

This screen is a subset of the Ecosystems screen and shows data for each paired Zigbee device. The Status, Temperature, Humidity and CO2 values will only be visible if they are supported by the device.

NOTE: Device X pages will only show up once devices have been paired.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Function Default value: None MV210-400	Wireless Device X - Function Shows status of installed Zigbee wireless device. None: No status reported to Room Controller Window: Window sensor installed Door: Door sensor installed Motion: Device set to detect motion Env. data: Temperature, Humidity, CO2 sensor installed Remove: Removes device from Device list Water: Water Leak sensor installed Refrig.: Refrigerator temperature sensor installed Freezer: Freezer temperature sensor installed Choices: 1=None, 2=Window, 3=Door, 4=Motion, 5=Env. data, 6=Remove, 7=Water, 8=Refrig., 9=Freezer

Configuration Parameters Default Value	Significance and Adjustments
Comm. status Default value: Not paired Read Only MSI212-402	Wireless Device X - Communication Status Shows if device is communicating with Room Controller Not paired: Device not paired Online: Device paired and online Invalid: Device was paired and Room controller detected a communication error (selected function does not match paired sensor functionality). Offline: Device paired but offline Display Readings: 1=Not paired, 2=Online, 3=Invalid, 4=Offline
Battery Default value: None Read Only MSI211-401	Wireless Device X - Battery Shows current status of battery in wireless device. Display Readings: 1=None, 2=Normal, 3=Low
Addr. Read Only CSV11-30	Wireless Device X - Address Shows unique IEEE (MAC) address of Zigbee wireless device
Status Default value: None Read Only Door status: BV1 Window status: BV3 Water status: BV46 Sensor type: MSI180-199 Status: MSI210-400	Wireless Device X - Sensor Type Wireless Device X - Status Shows the ZigBee wireless device status. Device status and values will be different depending on the type of device: <ul style="list-style-type: none"> • Door Contact Status: 1=Closed, 2=Opened • Window Contact Status: 1=Closed, 2=Opened • Motion Sensor: No Motion, Motion • Water Leak Sensor Status: 1=Normal, 2=Leak Display Readings: Sensor Type: 1=None, 2=Unknown, 3=Motion, 4=Contact, 5=Water, 6=Temp., 7=Temp./RH, 8=CO2 Status: 1=None, 2=Closed, 3=Opened, 4=No motion, 5=Motion, 6=Normal, 7=Leak
Temperature Read Only AI315-324, 355-364	Wireless Device X - Temperature Range: -40 to 185 °F (-40 to 85 °C)
Humidity Read Only AI365-384	Wireless Device X - Humidity Percent relative humidity Range: 0 to 100 %
CO2 Read Only AI385-404	Wireless Device X - CO2 Parts per million Range: 0 to 5000 PPM

DEVICE GROUPS

The Device Groups screen shows if a particular Zigbee wireless sensor is paired with the Room Controller.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Door installed Default value: No Read Only BV2	Door Contact Installed Shows if Door sensor installed. Display Readings: 1=No, 2=Yes
Win. installed Default value: No Read Only BV4	Window Contact Installed Shows if Window sensor installed. Display Readings: 1=No, 2=Yes
Water installed Default value: No Read Only BV45	Water Leak Sensor Installed Shows if Water Leak sensor installed. Display Readings: 1=No, 2=Yes

TEMPERATURE ALARMS CONFIGURATION

The Temperature Alarms Configuration screens show the values that trigger an alarm only for Zigbee wireless sensors with temperature measurement.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Enable Default value: Off MV151	Temperature Alarm Enabled Enables wireless device to alert Room Controller if temperature value reaches defined value in a particular paired device. Choices: 1=Off, 2=On
Hysteresis Default value: 2.0 °F (1.0 °C) AV210	Temperature Alarm Hysteresis Choices: 0 to 10°F (0 to 5.5 °C)
Ambient high Default value: 86.0 °F (30.0 °C) AV275	Ambient High Temperature Threshold Range: 32 to 122 °F (0 to 50 °C)
Ambient low Default value: 40.0 °F (4.5 °C) AV209	Ambient Low Temperature Threshold Range: 32 to 50 °F (0 to 10 °C)
Refrig. high Default value: 40.0 °F (4.5 °C) AV276	Refrigeration High Temperature Threshold (only present if a refrigeration sensor is installed) Range: 32 to 60 °F (0 to 16 °C)
Refrig. low Default value: 32.0 °F (0.0 °C) AV277	Refrigeration Low Temperature Threshold (only present if a refrigeration sensor is installed) Range: 32 to 50 °F (0 to 10 °C)
Freezer high Default value: 0.0 °F (-17.5 °C) AV278	Freezer High Temperature Threshold (only present if a freezer sensor is installed) Range: -40 to 32 °F (-40 to 0 °C)

ALARMS

The Alarms screen shows data for paired Zigbee wireless devices.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Low battery Default value: Off Read Only BV5	Low Battery Alarm Shows if any wireless paired device has a low battery status (On) or no paired device has low battery (Off). Display Readings: 1=Off, 2=On
Water leak Default value: Off Read Only BV44	Water Leak Shows if any water sensor paired device has detected a water leak (On) or no leak detected in any of the water sensor paired devices (Off). Display Readings: 1=Off, 2=On
Low temp. Default value: Off Read Only BV47	Low Temperature Shows if any temperature sensor paired device has detected a low temperature (On) or no low temperature detected in any of the temperature sensor paired devices (Off). Display Readings: 1=Off, 2=On
High temp. Default value: Off Read Only BV53	High Temperature Shows if any temperature sensor paired device has detected a high temperature (On) or no high temperature detected in any of the temperature sensor paired devices (Off). Display Readings: 1=Off, 2=On

Lua Screens

The Lua settings screens show information about any custom Lua script uploaded to the Room Controller. Lua scripts are not programmable on the Room Controllers. Lua scripts can be uploaded to the Room Controller via the Uploader Tool or via BACnet.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Program cmd Default value: Run	Program Command Run: Lua script activated and runs continuously until deactivated Stop: Lua script deactivated Choices: Stop or Run
Program status Default value: Idle Read Only	Program Status Running: Lua script active Halted: Lua script stopped and not active Idle: Lua script is running but not currently performing any actions Waiting: Lua script running and waiting for a response Uploading: Lua script currently unloading from Room Controller Loading: Lua script currently loading to Room Controller Display Readings: Idle, Loading, Running, Waiting, Halted, Unloading
Program error Default value: No error Read Only	Program Error No error: No errors in Lua script Syntax: Syntax error in Lua script detected Runtime: Runtime error occurred while running Lua script Memory: Device has run out of memory for the script Display Readings: No error, Syntax, Runtime, Memory

LUA GENERIC PARAMETERS

The Lua settings include twelve generic parameters that do not have a specific function or pre-configured functions. These parameters can be used in custom Lua scripts to store a value. They are also user configurable in their default state, but when assigned a value via a Lua script or via BACnet (Priority 1-16), they become read only (not configurable locally by the user) and the display color of the parameter changes to red. These parameters can also be configured via Zigbee, however they can still be modified locally by the user.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Parameter A (AV25) Default value: 0 AV25	Lua Parameter A (AV25) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter B (AV26) Default value: 0 AV26	Lua Parameter B (AV26) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter C (AV27) Default value: 0 AV27	Lua Parameter C (AV27) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter D (AV28) Default value: 0 AV28	Lua Parameter D (AV28) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter E (AV29) Default value: 0 AV29	Lua Parameter E (AV29) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter F (AV30) Default value: 0 AV30	Lua Parameter F (AV30) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter G (AV225) Default value: 0 AV225	Lua Parameter G (AV225) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter H (AV226) Default value: 0 AV226	Lua Parameter H (AV226) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter I (AV227) Default value: 0 AV227	Lua Parameter I (AV227) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter J (AV228) Default value: 0 AV228	Lua Parameter J (AV228) The value of this parameter depends on what is assigned to it from a BAS or Lua script.

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Parameter K (AV229) Default value: 0 AV229	Lua Parameter K (AV229) The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter L (AV230) Default value: 0 AV230	Lua Parameter L (AV230) The value of this parameter depends on what is assigned to it from a BAS or Lua script.

SECTION 4

Appendix A: Terminal Correspondence

The terminals of a VT8650 are identified differently and have a wider range of possible functions compared to those of any of the VT7600 series Room Controllers. Nonetheless, there is a direct correspondence of functions between the terminals of the VT7600 series and the VT8650 series. Consult the table below to verify the appropriate terminal when replacing a VT7600 Room Controller with a VT8650 Room Controller.

VT7600		VT8650	
Terminal name	Terminal ID	Terminal name	Terminal ID
Binary Input 1	BI1	Universal Input 16	UI16
Binary Input 2	BI2	Universal Input 17	UI17
Sensor Common	Scom	Terminal 18 Common	COM
Remote Sensor	RS	Universal Input 20	UI20 - RS
Sensor Common	Scom	Terminal 21 Common	COM
Mix/Supply Sensor	MS	Universal Input 22	UI22 - SS